




unIFY Control Panel

Clockaudio CDT3 Configuration





Attero Tech by QSC unIFY Control Panel Clockaudio CDT3 Configuration



The configuration software for the Clockaudio CDT-100 is organized into the following key sections:

- MIC Inputs
- LED Configuration

MIC Inputs



Dante™ TX Channel Name

This text field reports the Dante[™] transmit channel name shown on the Dante[™] network for corresponding analog input channel.

*Note: This field is non-editable. To edit the channel names, use the device list view control or use Dante™ Controller.

Dante™ TX Channel Status

This text field reports the number of active Dante[™] receive devices for the corresponding transmitter channel. If no devices are subscribed to the transmitter channel the text field will report "None".

*Note: This field is non-editable. To edit the channel names, use the device list view control or use Dante™ Controller.



Attero Tech by QSC unIFY Control Panel Clockaudio CDT3 Configuration

LED Configuration



TS -1 Controls

A red, a green, and a blue indictor show the state of the state of the LED's on the TS controlled to the CDT3. The state of every LED can be manually set from the application. Checking the checkbox next to the appropriate LED turn it on. The RGB fields can be used to alter the brightness of each LED. Values can be

adjusted from 0 to 255. There are separate controls for the green, red and blue LED's on each channel. Unchecking the checkbox turns that particular LED off regardless of the brightness setting.

The switch status shows the state of the TS switch and whether it is active or not.

*Note: The status indicators are read from the connected device in real time so when the state is changed, either manually or by a 3rd party system, there may be a short delay before the application status catches up.